## Adhesive instructions for impact protection



## ⚠ Important processing instructions:

- Working temperature from / to: +5 / + 35 °C;
- Clean surfaces before use! (free of grease, oil, dust, water, adhesives...).

## **Material**

- Glue for impact protection system (Art. E97003 / E97043)
- Cartridge applicator gun (not in scope of delivery)




The original color of the glue is black.

• Apply the glue\* to the back of the tile as shown. a gluing point should be about a diameter of approx. 3 cm and be 1 cm high.



## Attention:

- there must be applied 2 bis 3x traces of glue along the square edge.
- aplly a trace of glue with approx. 1 cm wide to the outer and sides edges.
- Tip: the glue trace on the outer edge can also be applied. directly to the frame to achieve a continuous seal against humidity from the outside.





• The glue is laid on in circular form on the out-standing squares and along the rounded edge.



Attention: there must be applied 3x thick traces of glue along the rounded edge.



- Place the impact protection tile flush on the frame and tap strongly.
- Repeat process with all tiles.



- Finally, fill the cavities with grit or humus to create a seamless level between the equipment and the ground.
- As a soil material in the safety area Eurotramp recommends the use of topsoil (natural soil), wood chips or alternatively impact protection with a maximum height of fall of at least 100 cm.