



## **Swings**


**J478** 












Play value :

1






## **Installation of equipment**

Impact area =

Impact area Free space



Zone d'Impact Sol souple Impact Area Wetpour Area de Impacto Fallraum bei synthetischem Fallschutz

Point de Référence Setting Dut Point Punto de referencia Bezugspunkt

2

¬ Zone d'Impact Sol fluent

ı	Impact Area Loose particle material
	Arenero
	Loses bei losem Bodenmaterial















1

2

1,4m

1,4m



21,5m<sup>2</sup>

28m<sup>2</sup>

21.5m<sup>2</sup> 98kg 2007-01-01