



Components



Installation of equipment

Impact area =

 Impact area
 Free space



1	0,6m	12m ²
2	0,8m	2,5m ²
3	1,1m	24m ²
4	2m	18,5m ²



2

07h00

2m³

57m²

318kg

22kg

EN

16 630