

### Substructure


The substructure must be frost-stable and level. The blocks can be installed directly over firmly compacted, stable-bearing substructures.

If the substructure is an existing paved surface (e.g. concrete or asphalt), level off any uneven spots (e.g. using leveling mortar).


If the substructure is not water-permeable, provide drain system.

### Installation

The EUROFLEX® variable sandbox edging can be made of plastic simply assemble connectors in the desired shape and size (smallest design square). The plastic stopper serves as a closure in the connection area.



Plastic connecting pipe



Plastic stopper to close the opening



All information without guarantee, subject to change. The installation instruction is not subject to any change service. Each current and valid from can be recalled at [www.kraiburg-relastec.com/euroflex/](http://www.kraiburg-relastec.com/euroflex/)

Additional floor anchoring is recommended in public areas.

These are inserted into the plastic pipe.

The ground anchors must be driven in or, if necessary, concreted in, depending on the nature of the ground become. Knock in the ground anchor 20 mm below the upper edge of the sandbox or set it in concrete.

The individual elements must not cut as they are steel-reinforced.

The ground anchors are available in two different lengths, 0.60m and 1.0m, the upper tube area is closed. This means that no plastic cap is required.



In order to avoid different discolorations from sunlight, please always cover the goods completely with the UV protective film (as delivered from the factory) until installation.